

Installation instructions for KZNG5-2793-00, KZNG5-2794-00
Under Run Protective Shield Fuel Tank

TOYOTA RAV4



LEXUS NX



Model year:

RAV4 - 2012 - 2015 -

NX

2014

Applicability:

ZSA44L-ANFXK; ZSA44L-ANXXK
ZSA44L-ANXGK; ZSA44L-ANYXKX
ZSA44L-ANYMKX; ALA49L-ANTGXX
ASA44L-ANTGKX; ASA44L-ANTMKX
ALA49L-ANTMXX; ZSA42L-ANYXKX
ZSA44L-ANFMKX; ZSA42L-ANYMKX
ZSA42L-ANFXKX; ALA49L-ANTGYW

all sfx
except NX300h

Part Number:

Steel: KZNG5-2793-00
Aluminium: KZNG5-2794-00



Weight:

Steel: 14.10 kg
Aluminium: 10.09 kg




Installation Time:

30 min


Rev.1 12.10.2015

A



KZNG5-02793-60

B




1x

C




1x

D




1x

E




1x

F



1x

G



M10x30

5x


H



d=10

5x


I



d=10


5x

J



h=10


1x




17 mm





1




FWD




see repair manual




2



FWD



3



17 mm






4

45 Nm



4



17 mm




4


45 Nm




5




FWD




6




FWD




17 mm




45 Nm



7



3



17 mm

4



45 Nm

2




1




E



8




3



17 mm

4



45 Nm

2



FWD




1



F



9




FWD







see repair manual





10



FWD



11



12

